

Finger Tube Application

Applying Benik's neoprene Finger Tubes to a very small or flaccid finger can be challenging. We have provided a rigid metal stay to assist in these cases.

- Match each finger tube to the appropriate finger using the labels inside each tube. (I=index M=middle R=ring P=pinkie)
- Slip the finger tube over the finger and attach the finger tube's Velcro® strap to the dorsal side of the splint. Adjust resistance for desired extension. Care should be taken to avoid hyperextension.
- In the case of a very small or flaccid finger, position the provided metal stay on the underside of the extended finger (**Figure A**). Ensure the metal stay remains in place to keep the finger in a rigid and extended position. Once the finger tube is in its desired position, pull out the metal stay.
- The seams of each finger tube are glued and taped, allowing them to be trimmed without compromising the seams or product.



Figure A

Contact the Benik customer service department at 1-800-442-8910 with any questions, comments or concerns.

BENIK
CORPORATION

11871 Silverdale Way NW, #107 • Silverdale, Washington 98383 USA
Phone (360) 692-5601 • Fax (360) 692-5600
www.benik.com • info@benik.com

Finger Tube Application

Applying Benik's neoprene Finger Tubes to a very small or flaccid finger can be challenging. We have provided a rigid metal stay to assist in these cases.

- Match each finger tube to the appropriate finger using the labels inside each tube. (I=index M=middle R=ring P=pinkie)
- Slip the finger tube over the finger and attach the finger tube's Velcro® strap to the dorsal side of the splint. Adjust resistance for desired extension. Care should be taken to avoid hyperextension.
- In the case of a very small or flaccid finger, position the provided metal stay on the underside of the extended finger (**Figure A**). Ensure the metal stay remains in place to keep the finger in a rigid and extended position. Once the finger tube is in its desired position, pull out the metal stay.
- The seams of each finger tube are glued and taped, allowing them to be trimmed without compromising the seams or product.



Figure A

Contact the Benik customer service department at 1-800-442-8910 with any questions, comments or concerns.

BENIK
CORPORATION

11871 Silverdale Way NW, #107 • Silverdale, Washington 98383 USA
Phone (360) 692-5601 • Fax (360) 692-5600
www.benik.com • info@benik.com